


NASA Crew Personal Active Dosimeters (CPADs)

**Leveraging Novel Terrestrial Personal Radiation
Monitoring Capabilities for Space Exploration**

TCC Radiation Technologies Event


9/21/16

Martin Leitgab



1) Novel Capabilities in Terrestrial Personal Radiation Dosimeters Yet Unused in Space

- Currently used NASA personal dosimeters (ISS): **Passive dosimeters**
 - * **To be returned to ground** upon mission completion for analysis
 - * **No in-flight exposure information**
 - * Integral exposure information over entire mission, **no time resolution**



- Novel capabilities in terrestrial personal dosimeters:
 - * **Active dosimeters**: configurable/autonomous recording of radiation exposure and internal storing of data
 - * **Displays** for immediate user exposure feedback
 - * **Wireless data transmission**



Opportunities to enhance Crew personal dosimetry with new features in terrestrial dosimeters

2) Technology Need for Exploration Mission 2 and Beyond



- **Requirements:** Need for wearable **personal active dosimetry**, capable of:
 - 1) Measuring **time resolved** and time integrated absorbed dose
 - 2) Operating for 30 days without being charged or requiring data download
 - 3) Being read out by the crew via a **display on the dosimeter**

Requirement not met with existing NASA radiation hardware (passive dosimeters)



Space Radiation Analysis Group (SRAG, SD2) develops
COTS-based **Crew Active Personal Dosimeters (CPADs)** to meet requirements

- **Derived requirements from intent of basic requirements:**

a. Inobtrusiveness to Crew during mission operations

- @ To minimize health risk projection uncertainties, CPADs to be worn at all times
- @ CPADs need to be changed in all garment changes
- @ Any additionally required Crew interaction to be avoided (e.g. data Xfer, power)

b. Accurate detection of space radiation environment (charged particles)

3) Market Survey/Technology Downselect

- Use COTS products/base to minimize resource footprint of project

- * Conduct Market Survey and Technology Downselect:

- @ Review COTS radiation detection technology options

- @ Identify most suitable radiation detection technology/implementation and vendor

- Apply basic selections to identify/downselect COTS candidate dosimeters:

- Action a):** Identify dosimeters with needed features (keeps development gap small):

- @ Ready-to-purchase, packaged products (no research papers/components)

- @ Battery powered

- @ Capable of record time-stamped dose

- @ Readout via common interface to laptop

- @ Small ($<100 \text{ cm}^3$) & lightweight ($<100\text{g}$)

➡ **Result a)** Selected 2 Direct Ion Storage and 3 Silicon Diode COTS dosimeter candidates

3) Market Survey/Technology Downselect

| Candidate Detection Technology | Comment |
|---------------------------------|--|
| Silicon diodes | Established (30 yrs), low power, small size, rugged; calibration potentially LET/energy dependent; used by IPs (ESA, JAXA) |
| Direct Ion Storage (DIS) | Established (20 yrs), low power, small size, rugged; used by IPs (ESA) |
| CsI(Tl) crystals | Too high power consumption, charged particle response probably not adequate |
| GM tubes | Only counter, charged particle response not adequate |
| Ionization chambers | Too large, too high power |
| MOSFET | No packaged product available; sensitivity probably not adequate; used by IPs (ESA) |


| Cand. Company, Product | Technology | Comment | Acquisition Status |
|-------------------------------|------------|---|---------------------------|
| Mirion, Instadose 1 | DIS | No time resolved recording | Loaned for DIS assessment |
| Mirion, Instadose 2 | DIS | Fulfills all criteria; pre-release beta hardware | Courtesy from Mirion |
| Mirion, DMC 3000 | Si diode | Fulfills all criteria | Purchased |
| Thermo Fisher Scientific, EPD | Si diode | Fulfills all criteria (memory limit on dose storage) | Purchased |
| Fuji Electric Co, NRF-30 | Si diode | Fulfills all criteria (no zero suppression in dose reads) | Purchased |




4) Technology Downselect

Action b) Test dosimeter candidates in space-relevant charged particle radiation fields

Result b) Tests selected Mirion DIS as sole feasible COTS technology & implementation



Radiation Testing @ TRIUMF, NSRL



- Mirion Technologies holds patents on DIS technology
 - > Selected as sole source vendor

5) CPAD Development Core MPCV Requirements

- Flow high level requirements to functional level to formulate development contract
- Leverage existing COTS features with additional new features to meet all CPAD requirements




- MPCV Operations Requirements

| Category | Flowed Down Requirement | Comment |
|---|---|---|
| Size/form factor, weight | Within 20% if Instadose 1: < 3 x 1 0.6"; < 50 g | Close to existing |
| Battery | Life 30+90 days, capacity < 200mAh | Exceeded by existing |
| Data storage | >= 4500 points | Exceeded by existing |
| | 'Dynamic read': only record dose if beyond 20 muGy resolution (at most once per minute) | New feature (exists in industry) |
| Non-shatterable display | Display cumulative absorbed dose since mission start and dose over last 10 minutes ('rate') | New feature (exists in industry) |
| Bluetooth Wireless Data Transmission | Retain | Exceeding by existing, too costly to remove from design |
| Reset buttons for display and BLE processor | | New feature (exists in industry) |

6) Requirement Extension Leveraging Synergy between ISS and MPCV Programs

- **Benefits for ISS Program** from use of CPADs as operational personal dosimeters:
 - * **Reduced ground processing cost/time**
 - * Reduced up-down logistics
 - * Near real-time data availability
- **Benefits for MPCV Program:** ISS agreed to fund **2017 Technology Demonstration Mission** with opportunity to validate derived requirements from intent of basic requirements (inobtrusiveness to Crew, accurate space radiation measurement)



- ISS Additional Operations Requirements

| Category | Flowed Down Requirement | Comment |
|--------------------------------------|---|----------------------------------|
| Battery compartment | Tool-free accessibility | New feature (exists in industry) |
| Battery | Life 8 months, capacity < 200mAh | Exceeded by existing |
| Bluetooth Wireless Data Transmission | Autonomous data transfer to webserver, transmission quality assurance, databasing | Exceeding by existing |


7) CPAD Near-/Mid-Term Project Schedule

- **Accelerated schedule** due to use of COTS base and vendor:

- * 8/26/16 Contract start date
- * 9/23/16 Deliverables due- basic board schematics and layouts
- * 12/1/16 Deliverables due- pre-final drawings, bill of materials
- * 2/15/17 First delivery of 6 CPADs
- * 3/10/17 Final delivery of 14 CPADs
- * Feb/Mar 2017 Acceptance and radiation testing
- * June/July 2017 Anticipated ISS technology demonstration (SpX-12 or similar)
- * Aug/Sep 2017: Contingent on successful verification of CPAD performance:
 - @ Completion of technology demonstration analysis
 - @ Preparation for operational use of CPADs on ISS
 - @ Start of EM-1 certification activities

Backup


3) Technologies Overview- Si Diodes




3) Technologies Overview- Direct Ion Storage

- Established: used for 20 years
- Hardware: MOSFET transistor with floating gate: stores variable amounts of charge (analog) isolated from other components (configurable); read by measuring channel conductivity/voltage of transistor between source and drain (does not disturb charge on floating gate); ion chamber on top of MOSFET
- Radiation detection:
 - * Floating gate exposed to air/gas volume where ionizing radiation produces electron-ion pairs; electric field of bias on floating gate ($\sim 30\text{V}$) collects charge carriers
 - * Photon response: wall material initial interaction, secondary electrons ionize air/gas
 - * Charged particle response: wall sufficiently thin \rightarrow deposit readable energy in air/gas
- \rightarrow change dosimetric characteristics by changing wall material & thickness (few mm), gas

Standard Analog EEPROM memory cell




DIS memory cell



- Advantages: Compact, good sensitivity ($\sim 5\text{-}10\text{ }\mu\text{Gy}$), low power (readout only when desired), rugged components, simple instrumentation (low cost), can zero floating gate if exposed to high dose; fading $<5\%$ over 1 year, no impact of rel. humidity or temperature
- Disadvantages: Not as established as silicon diodes; calibration potentially energy/LET dependent

3) Technologies Overview- Direct Ion Storage

- Instadose 1 and 2 COTS products: licensed for dosimetry market



Two DIS detectors
(shallow & deep)

